



24076 Reedy Dr.
Elkhart, IN 46514
(219)-266-5551 (Office)
(219)-206-9296 (Fax)

U-PLATE SEAL INSTALLTION

1. Move Room to have access to Glide Block in access hole cutout.
2. Remove bolts from Glide Blocks - Be Sure Not To Rotate Glide Block to Get It Out Of Position.
3. Remove wood screws securing the tabs of bottom center piece wall frame to coach.
4. Push floor out approximately 75 to 80 percent to open postion.
5. From inside of coach, carefully tilt room up as much as possible to gain access to tabs of bottom centerpiece of wall frame.
6. Slide U-plate Seal in place around existing tab on bottom centerpiece of wall frame. Be sure to align rear through holes on U-plate with through holes for removed wood screws holes on tab of bottom centerpiece of wall frame.
7. Replace wood screws removed from step 3 going through U-Plate through holes and through holes on tabs of bottom centerpiece wall frame.
8. Using Low Profile self tapping screws, screw through existing through holes on U-plate and into tabs of bottom centerpiece of wall frame.
9. Remove orange tape from bottom of overhanging excess L-shape wipe.
10. Replace Glide Block Screws removed from step 2.

NOTE: IT IS LIFTCO'S RECOMMENDATION THAT THE CARPET AROUND EACH TAB OF BOTTOM CENTER PIECE BE REMOVED FOR PROPER INSTALLATION.

THIS PROCESS IS PRELIMINARY ONLY AND SUBJECT TO CHANGE AS SO REQUIRED.